



1" Galvanized Pipe Cut with Saw

2009 2 17



Thoroughly Knead Putty

2009 2 17



Apply Putty to the Break

2009 2 17



Press Putty Firmly into the Repair

2009 2 17



Putty Applied to Break

2009 2 17



Water Added to Wrap

2009 2 17



Apply Wrap to Putty

2009 2 17



Wrap Tightly

2009 2 17



Apply 8 to 10 Wraps over the Putty

2009 2 17



Fully Wrapped

2009 2 17



Keep Tight with Twisting Motion

2009 2 17



Keep Tightening as the Wrap Gets Sticky



Keep Tightening as the Wrap Gets Sticky

2009 2 17



Keep Tightening as the Wrap Gets Sticky

2009 2 17



Finished Repair Under 55psi Water Pressure Test

2009 2 23